

Commercial Warehouse Load Calculator

Organize warehouse lighting, equipment, and process rows into connected VA, adjusted VA, and line current using explicit row factors.

Generated October 10, 2026

<https://www.elecatrix.com/commercial-industrial-loads/commercial-warehouse-load-calculator/>

Inputs

Input	Value	Unit
Warehouse load rows	Rows: 3	
Row 1 - Load label	High-bay lighting	
Row 1 - Connected load	48000	VA
Row 1 - Demand factor	100	%
Row 1 - Continuous multiplier	125	%
Row 2 - Load label	Battery charging area	
Row 2 - Connected load	36000	VA
Row 2 - Demand factor	80	%
Row 2 - Continuous multiplier	100	%
Row 3 - Load label	Conveyor equipment	
Row 3 - Connected load	60000	VA
Row 3 - Demand factor	70	%
Row 3 - Continuous multiplier	100	%
System voltage	480	V
Phase model	Three-phase	

Results

Result	Value	Unit
Connected load	144000	VA
Entered-demand warehouse load	118800	VA
Continuous-load adder	12000	VA

Commercial Warehouse Load Calculator

Organize warehouse lighting, equipment, and process rows into connected VA, adjusted VA, and line current using explicit row factors.

Generated October 10, 2026

<https://www.elecatrix.com/commercial-industrial-loads/commercial-warehouse-load-calculator/>

Adjusted warehouse load	130800	VA
Line current	157.3279	A
Load row count	3	rows
Phase multiplier	1.7321	x
Calculation details		

Detail	Value	Unit
Calculation basis	Each entered load row receives its entered demand factor and continuous multiplier before current conversion.	
Planning boundary	Mode worksheet only; no occupancy table, feeder selection, service sizing, or authority determination is made.	

Formulas

$$D_i = S_i \times \frac{F_{d,i}}{100}$$

$$A_i = D_i \times (\frac{F_{c,i}}{100} - 1)$$

$$S_{adjusted} = \sum_i (D_i + A_i)$$

$$I = \frac{S_{adjusted}}{V \times k_{phase}}$$

Warnings and limitations

This mode uses entered warehouse load assumptions. It does not select a demand table or determine project requirements.